


# HP LaserJet 3390/3392 All-in-One Service Manual





# HP LaserJet 3390/3392 All-in-One

---

Service Manual



## Copyright information

© 2005 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number Q6500-90901

Edition 2, 10/2005

## Safety information

**WARNING!**

Potential Shock Hazard

Always follow basic safety precautions when using the all-in-one to reduce risk of injury from fire or electric shock.

Read and understand all instructions in the user guide.

Observe all warnings and instructions marked on the all-in-one.

Use only a grounded electrical outlet when connecting the all-in-one to a power source. If you do not know whether the outlet is grounded, check with a qualified electrician.

Do not touch the contacts on the end of any of the sockets on the all-in-one. Replace damaged cords immediately.

Unplug the all-in-one from wall outlets before cleaning.

Do not install or use the all-in-one near water or when you are wet.

Install the product securely on a stable surface.

Install the all-in-one in a protected location where no one can step on or trip over the power cord and where the power cord will not be damaged.

If the all-in-one does not operate normally, see the online user guide.

Refer all servicing questions to qualified personnel.

Information regarding FCC Class B, Parts 15 and 68 requirements can be found in the user guide.

## Trademark credits

Microsoft® and Windows® are U.S. registered trademarks of Microsoft Corporation.

Linux is a U.S. registered trademark of Linus Torvalds.

UNIX® is a registered trademark of The Open Group.

PostScript® is a trademark of Adobe Systems Incorporated.

Energy Star® and the Energy Star logo® are U.S. registered marks of the United States Environmental Protection Agency.



## FCC Regulations

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If this equipment is not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase separation between equipment and receiver.

Connect equipment to an outlet on a circuit different from that to which the receiver is located.

Consult your dealer or an experienced radio/TV technician.

Any changes or modifications to the printer that are not expressly approved by HP could void the user's authority to operate this equipment.

Use of a shielded interface cable is required to comply with the Class B limits of Part 15 of FCC rules.

This equipment complies with FCC rules, Parts 15 and 68. On the back of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company. The REN is used to determine the quantity of devices which may be connected to the telephone line. Excessive RENs on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all, areas, the sum of the RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to the line, as determined by the total RENs, contact the telephone company to determine the maximum REN for the calling area.

This equipment uses the following USOC jacks: RJ11C.

An FCC-compliant telephone cord and modular plug is provided with this equipment.

This equipment is designed to be connected to the telephone network or premises wiring using a compatible modular jack which is Part 68 compliant. This equipment cannot be used on telephone company-provided coin service. Connection to Party Line Service is subject to state tariffs. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make the necessary modifications in order to maintain uninterrupted service. If trouble is experienced with this equipment, please see the numbers in the front of this manual for repair and (or) warranty information. If the trouble is causing harm to the telephone network, the telephone company may request you remove the equipment from the network until the problem is resolved. The following repairs can be done by the customer: Replace any original equipment that came with the device. This includes the print cartridge, the supports for trays and bins, the power cord, and the telephone cord. It is recommended that the customer install an ac surge arrestor in the ac outlet to which this device is connected. This is to avoid damage to the equipment caused by local lightning strikes and other electrical surges.

See the electronic user guide for more regulatory information.



# Table of contents

## 1 Product information

Quick access to all-in-one information .....	2
All-in-one configurations .....	3
All-in-one features .....	5
Product walkaround .....	7
HP LaserJet 3390/3392 all-in-one .....	7
Interface ports .....	9
Control panel .....	9
Model and serial numbers .....	10
Software description .....	11
Supported drivers .....	11
Additional drivers .....	11
Software installation .....	12
Typical installation .....	12
Minimum installation .....	12
Software for Windows .....	13
Software components for Windows .....	13
HP ToolboxFX .....	13
Embedded Web server (EWS) .....	13
Software for Macintosh .....	14
HP Director .....	14
Macintosh Configure Device (Mac OS X V10.3 and Mac OS X V10.4) .....	14
PDEs (Mac OS X V10.3 and Mac OS X V10.4) .....	15
Uninstalling software .....	16
Windows .....	16
Macintosh .....	16
Media specifications .....	17
Supported media weights and sizes .....	17
Media to avoid .....	18
Media that can damage the all-in-one .....	19

## 2 Installation

Operating environment .....	22
Minimum system requirements .....	23
Unpacking .....	24
Installing input devices .....	25
ADF input tray .....	25
250-sheet input tray (tray 3) .....	26
Installing the control-panel faceplate .....	27

Loading media .....	28
Loading documents to fax, copy, or scan .....	28
Loading the single-sheet priority input slot (tray 1) .....	30
Loading tray 2 or optional tray 3 .....	30
Installing accessories .....	32
Removing and replacing a DIMM .....	32

### 3 Maintenance

Managing supplies .....	36
Life expectancies of supplies and the all-in-one .....	36
Ordering supplies .....	36
Storing print cartridges .....	37
Replacing and recycling supplies .....	37
Replacing the print cartridge .....	39
Replacing the staple cassette .....	42
Replacing the tray 2 pickup roller .....	44
Replacing the tray 2 and optional tray 3 separation pad .....	49
HP policy on non-HP supplies .....	52
Resetting the all-in-one for non-HP supplies .....	52
HP fraud hotline .....	52
Cleaning the all-in-one .....	53
To clean the exterior .....	53
Cleaning the flatbed scanner glass .....	53
Cleaning the scanner-cover backing .....	55
Cleaning the tray 2 pickup roller .....	56
Cleaning the ADF pickup-roller assembly .....	60
Cleaning the print path .....	63
Managing the all-in-one .....	65
Information pages .....	65
Using the HP ToolboxFX .....	68
To view the HP ToolboxFX .....	68
Status .....	68
Event log .....	69
Alerts .....	69
Set up status alerts .....	69
Set up e-mail alerts .....	69
Fax .....	70
Fax tasks .....	70
Fax phone book .....	70
Fax send log .....	73
Fax receive log .....	73
Help (Documentation) .....	73
System settings .....	74
Device information .....	74
Paper handling .....	75
Print quality .....	75
Paper types .....	75
System setup .....	76
Service .....	76
Device Polling .....	76

Print settings .....	76
Printing .....	76
PCL 5e .....	77
PostScript .....	77
Network settings .....	77
Using Macintosh Configure Device (Mac OS X V10.3 and Mac OS X V10.4) .....	78
Understanding the Embedded Web server .....	79
Features .....	79

## 4 Theory of operation

Basic operation .....	82
Sequence of operation for the base unit .....	82
Scanner and ADF functions and operation .....	84
Scanner functions .....	84
Scanner operation .....	85
ADF operation .....	85
ADF paper path and ADF sensors .....	86
ADF jam detection .....	87
Internal components (base unit) .....	88
Engine control system .....	90
Laser/scanner system .....	92
Pickup/feed/delivery system .....	93
Image-formation system .....	95
Fax functions and operation .....	99
Computer and network security features .....	99
PSTN operation .....	99
To receive faxes when you hear fax tones .....	100
Distinctive ring function .....	100
Faxing with Voice over IP services .....	101
The fax subsystem .....	101
Formatter in the fax subsystem .....	101
LIU in the fax subsystem .....	102
Safety isolation .....	102
Safety-protection circuitry .....	102
Data path .....	103
Hook state .....	103
Downstream current detection .....	103
Hook switch control .....	104
Ring detect .....	104
Line current control .....	104
Billing- (metering-) tone filters .....	104
Fax page storage in flash memory .....	105
Stored fax pages .....	105
Advantages of flash memory storage .....	105

## 5 Removal and replacement

Introduction .....	108
Removal and replacement strategy .....	108
Electrostatic discharge .....	108
User-replaceable parts .....	109

Required tools .....	109
Before performing service .....	109
After performing service .....	110
Post-service tests .....	110
Test 1 (print-quality test) .....	110
Test 2 (copy-quality test) .....	110
Test 3 (fax-quality test) .....	111
Parts removal order .....	112
Remove the print cartridge .....	113
External panels, covers, and doors .....	114
Right cover .....	114
Left cover .....	116
Print-cartridge door .....	118
Rear cover .....	120
Top cover .....	122
Replacing the ADF pickup-roller assembly .....	124
ADF assembly .....	127
Scanner/ADF assembly .....	129
Bezel and control panel .....	131
Internal assemblies .....	134
Convenience-stapler assembly (HP LaserJet 3392 only) .....	134
Convenience-stapler power supply (HP LaserJet 3392 only) .....	136
Convenience-stapler ac inlet cable (HP LaserJet 3392 only) .....	138
Convenience-stapler power supply bracket and strap (HP LaserJet 3392 only) .....	139
Speaker .....	140
Power-switch PCA .....	142
Formatter .....	143
Duplex assembly .....	146
Laser/scanner .....	148
Memory-tag-reader assembly .....	150
Fuser .....	152
Fan .....	152
Duplex-drive gears .....	154
Duplex solenoid .....	155
Fuser .....	157
Interlock assembly .....	163
ECU .....	164
Main motor .....	169
Pickup-and-feed assemblies .....	171
Transfer roller .....	171
Registration-roller assembly .....	172
Main gear assembly and tray 2 pickup solenoid .....	173
<b>6 Troubleshooting</b> .....	
Troubleshooting process .....	178
Troubleshooting checklist .....	178
Jams .....	181
Causes of jams .....	181
Tips to avoid jams .....	182
Where to look for jams .....	182

Jams in the print-cartridge area .....	183
Jams in the trays .....	186
Jams in the output bin .....	191
Jams in the straight-through output path .....	192
Jams in the duplex path .....	194
Jams in the ADF .....	199
Jams in the convenience stapler (HP LaserJet 3392 only) .....	204
Control-panel messages .....	207
Alerts and warning messages .....	207
Critical-error message-tables .....	212
Print problems .....	215
Print-quality problems .....	215
Improving print quality .....	215
Understanding print-quality settings .....	215
To temporarily change print-quality settings .....	215
To change print-quality settings for all future jobs .....	216
Identifying and correcting print defects .....	217
Print-quality checklist .....	217
General print-quality issues .....	217
Media-handling problems .....	222
Print-media guidelines .....	222
Solving print-media problems .....	222
Performance problems .....	224
Scan problems .....	225
Solving scanned-image problems .....	225
Scan-quality problems .....	227
Preventing problems .....	227
Solving scan-quality problems .....	227
Copy problems .....	228
Preventing problems .....	228
Image problems .....	228
Media-handling problems .....	229
Performance problems .....	231
Fax troubleshooting .....	232
General fax troubleshooting .....	232
Problems receiving faxes .....	234
Problems sending faxes .....	236
Voice-call problems .....	238
Media-handling problems .....	238
Performance problems .....	239
Control-panel display problems .....	240
Convenience-stapler problems (HP LaserJet 3392 only) .....	240
DSL problems .....	241
PABX line problems .....	241
ADF problems .....	242
Functional checks .....	244
Drum rotation test .....	244
Engine test .....	245
Half self-test functional check .....	246
To perform a half self-test check .....	246

To perform other checks .....	246
Heating element check .....	247
High-voltage contacts check .....	247
To check the print-cartridge contacts .....	247
To check the high-voltage connector assembly .....	248
Service-mode functions .....	249
NVRAM initialization .....	249
Secondary service menu .....	249
Troubleshooting tools .....	251
All-in-one pages and reports .....	251
Demo page .....	251
Configuration page .....	251
Supplies Status page .....	251
Fax reports .....	252
Fax activity log .....	252
Fax call report .....	252
Phone book report .....	252
Billing-code report .....	253
HP ToolboxFX .....	253
To view HP ToolboxFX .....	253
Troubleshooting tab .....	253
Service menu .....	254
Restoring the factory-set defaults .....	254
Cleaning the paper path .....	254
T.30 protocol trace .....	255
Archive print .....	255
Firmware updates and recovery .....	256
Firmware update by using a flash executable file .....	256
Firmware-recovery DIMM .....	256

## 7 Parts

Accessories and ordering information .....	259
Supplies .....	260
Memory .....	260
Cable and interface accessories .....	260
Paper-handling accessories .....	261
Scanner/ADF replacement parts .....	261
Control-panel bezels .....	262
Supplementary documentation and support .....	263
Troubleshooting diagrams .....	266
Repetitive image defects .....	266
Interface connectors .....	267
Formatter connectors .....	268
Line interface unit (LIU) .....	269
Solenoids .....	270
Switches and sensors .....	271
Rollers and pads .....	272
PCAs (base unit) .....	273
Major components (base unit) .....	274
Scanner and ADF .....	275

Circuit diagram .....	276
How to use the parts lists and diagrams .....	278
Types of screws .....	278
Scanner and ADF assemblies .....	280
Scanner components .....	282
ADF components .....	284
Convenience stapler components (HP LJ 3392 only) .....	286
Formatter, LIU, HP jewel, and nameplate .....	288
External covers and panels .....	290
Internal components (1 of 4) .....	292
Internal components (2 of 4) .....	294
Internal components (3 of 4) .....	296
Internal components (4 of 4) .....	298
Engine-controller assembly .....	300
Main-drive assembly .....	302
Duplexing-drive assembly .....	304
Tray 2 cassette and tray 3 cassette/feeder .....	306
Duplexing assembly .....	308
Fuser assembly .....	310
Alphabetical parts list .....	312
Numerical parts list .....	317

#### Appendix A All-in-one specifications

Physical specifications .....	324
Supplies specifications .....	324
Performance .....	325
Electrical specifications .....	327
Power consumption .....	327
Environmental specifications .....	328
Acoustic emissions .....	328

#### Appendix B Warranty information

Hewlett-Packard limited warranty statement .....	330
Print Cartridge Limited Warranty Statement .....	331
Extended warranty .....	332

#### Appendix C Regulatory statements

Declaration of conformity (HP LaserJet 3390, 3392, 3055, and 3050) .....	334
Country/region-specific safety statements .....	335
Laser safety statement .....	335
Canadian DOC statement .....	335
Korean EMI statement .....	335
Finnish laser statement .....	336
Japan power cord statement .....	336

<b>Index .....</b>	<b>337</b>
--------------------	------------